

Talon Snappit Range

Snappit



Talon, Units 2 to 5 Chieftain Close, Gillingham Business Park, Kent, ME8 OPP Tel: 01634 268811 • Fax: 01634 268812 • Email: sales@talon.co.uk • Web: www.talon.co.uk Version: 2 Page 1 of 2 15.03.19


Talon How to -Install Talon Snappit

Snappit cover is easy to fit and remove. Snappit is useful as it forms a light protective barrier around pipes and offers a good finish.

Snappit stops the need to paint pipework.

Step 1

Measure and cut Snappit Cover to desired length.




Push the open side of the cover onto the pipe. Snappit Cover will flex and snap into position to grip the pipe.

Step 2 Fit the snappit to the pipe.



Rotate the cover until the open side is out of direct view



Snappit Cover is compatible with plastic or copper pipe.

It is suitable for use with heated radiator or general domestic hot water pipe.

Step 4

Trim and fit Snappit Cover to most straight pipe installations.

Information Sheet No. 3A – © Talon Manufacturing Talon, Units 2 to 5 Chieftain Close, Gillingham Business Park, Kent, ME8 OPP Tel: 01634 268811 • Fax: 01634 268812 • Email: sales@talon.co.uk • Web: www.talon.co.uk Version: 2 Page 2 of 2 15.03.19